



TECHNICAL INSTALLATION GUIDE FOR KARMA ACOUSTIC JOISTHOOD ON PRE-COMPLETION TESTING AND OTHER TIMBER JOIST SEPARATING FLOORS

- Care should be taken to comply with all relevant building and safety regulations
- The Karma Acoustic JoistHood can be fitted from either above or below or before the joists are installed
- Make sure that the joist is clean, level and free of debris
- For traditional timber joists the jaws of the cap are slightly less than the joist width to ensure a tight fit. Simply open the jaws and sit the joist cap over the joist ensuring the base is located tightly with the joist surface
- For engineered joists the profile is designed to give the same stable fit, although in this case the joist cap is slid onto the joist from one end prior to installing the joist.
- In all cases Karma Acoustic Perimeter Strip must be laid in the perimeter to ensure that the floating floor is fully isolated from the structural floor and walls.



Website www.karma-acoustics.co.uk
Email technicalservices@karma-acoustics.co.uk
Telephone 0870 950 9992
Fax 0870 950 9993



UK Timber Frame Association

Specify-it

FASTRACKCAD[®]
ARCHITECTURAL CAD DATABASES