



## **TECHNICAL INSTALLATION GUIDE FOR KARMA ACOUSTIC MAT FOR CONCRETE PRE-COMPLETION TESTING SEPARATING FLOORS AND OTHER CONCRETE SUB-FLOORS**

- Before laying the Karma Acoustic Mat ensure the concrete sub-floor is sound, level, smooth, dry and free of dust and dirt.
- As Karma Acoustic Mat stretches slightly when rolled up it must be unrolled where it is to be installed and left for a few hours before installing.
- Karma Acoustic Mat Adhesive is recommended to bond the product to the base floor
- When laying Karma Acoustic Mat into the adhesive, ensure you press from the centre outwards in order to exclude air and maximise contact with the adhesive.
- Roll the Karma Acoustic Mat from end to end and side to side to ensure maximum contact. Use a 68kg flooring roller.
- Cut to size using a craft knife and straight edge. Ensure all edges are butt jointed.
- Once you have completely covered the floor, wait 30 minutes then roll again.
- Wait until the adhesive is fully set before moving furniture or any other loads on the Karma Acoustic Mat.



**Website**      [www.karma-acoustics.co.uk](http://www.karma-acoustics.co.uk)  
**Email**          [technicalservices@karma-acoustics.co.uk](mailto:technicalservices@karma-acoustics.co.uk)  
**Telephone**    0870 950 9992  
**Fax**              0870 950 9993



**UK Timber Frame Association**

**Specify-it**

**FASTRACKCAD**  
ARCHITECTURAL CAD DATABASES