



TECHNICAL INSTALLATION GUIDE FOR KARMA ACOUSTIC TRIPLEMAT ON PRE-COMPLETION TESTING AND OTHER TIMBER SEPARATING FLOORS

- 12mm Karma Acoustic Triple Mat can be laid under all final floor finishes
- It can be laid either loosely or bonded to the floor with Karma Acoustic Mat Adhesive
- Ensure the floor is clean and dry before bonding
- Always ensure the Karma Acoustic Triple Mat sits tightly against the wall or skirting board to prevent flanking or airborne noise
- When fitting carpets over the Karma Acoustic Triple Mat ensure the adhesive is suitable for use
- Carpets can be laid straight onto the Karma Acoustic Triple Mat and can be glued or fastened using Karma Acoustic Triple Mat Gripper Rods
- When fitting a laminate floor over the Karma Acoustic Triple Mat bond a layer of 6mm plywood to the Karma Acoustic Triple Mat before laying the laminated floor
- When fitting vinyl flooring over the Karma Acoustic TripleMat bond a layer of 6mm plywood to the Karma Acoustic TripleMat before laying the vinyl



Website www.karma-acoustics.co.uk
Email technicalservices@karma-acoustics.co.uk
Telephone 0870 950 9992
Fax 0870 950 9993



UK Timber Frame Association

Specify-it

FASTRACKCAD[®]
ARCHITECTURAL CAD DATABASES